



ILIKE F PRO

Quick User Guide

**For more information, refer to the user manual for our website.
The PDF form file is available.**

Thank you for choosing ILIKE Smart phone!

To make the best use of your phone, please read this manual carefully.

ILIKE is an Android intelligent mobile phone, it has the ultra-thin fashion appearance, it supports application software installation and unloading from Android electronic market, WLAN network connection, touch capacitive screen.

These will lead you into an entirely new and fascinating mobile internet world.

This manual systematically introduces many functions of ILIKE Smart phone, tips and notes.

The illustrations in this manual are only for reference, and their functions are based on the real product. The company reserves the right of final interpretation.

Basic Information

Safety Notice

When you contact with telecom department or commission agents, they need to know your phone IMEI number (printed on the label on the back of the phone and can be found after taking down the battery). Please copy the number and keep it safe for future use.

Install and Unload SIM Card

Before using the phone, you must insert valid SIM (Subscriber Identity Module) card in the phone. SIM card provided by network supplier.

Power off the phone, remove the rear cover, battery or other external power supply.

Make the end of SIM card without cutting angle inside and aim at the card slot of the phone and metal surface of SIM card face downward, then insert SIM card to the card slot of the phone, the other SIM card is also inserted in this way.

When taking out SIM card, directly pull it outward and then can take out SIM card.

Install and Unload MICRO SD Card

Aim at the T card slot and push the T card gently, and the card will be inserted correctly.

Prompt: If the memory card is failed, please check whether it is correctly placed and good contact of metal point.

Install and Unload Battery

Take off the rear cover of the mobile. Make one end of battery with metal surface aim at the battery connector. Then gently press the battery downward using the finger, and then press the other end to install the battery.

Prompt: Please operate correctly to avoid damaging the battery connector.

Charging

Insert the charger on the charging interface at the top of the phone. After inserting the charging plug, battery strength icon stripe at the top right corner of the screen is scrolling, which means that the charging is processing; when the stripe is full of the whole icon and stop scrolling, which means that the battery charging is completed; when the charging is completed, please pull out the plug.

When electric quantity is not enough, warning message will be sent; and electric quantity shows empty. When electric quantity is too low, the phone will power off automatically. Please don't make the battery in the status of not enough electric quantity for a long time; otherwise it may damage the battery quality and service life. Please don't charge the battery for a long time.

Prompt: *In order to ensure normal operation of the phone, please make sure to use the designated charger.*

Quick User Guide

The phone has not only the basic functions of mobile phone, but also support rich, practical and rapid feature functions, can be briefly introduced as follows:

Power On/Off

In the power-off mode, long press **[Power]** key, it will power on; otherwise. In the power-on, long press **[Power]** key, and choose **Power off**, it will power off. If you set up SIM lock or phone lock, please input the code according to the requirements.

In any other interface, short press this button to lock the screen.

Warning: *As mobile phone can cause interference and dangerous where you are prohibited to use mobile phone, please power off your mobile phone.*

Turn On /Off Screen

Turn Off Screen

Please short press [Power] to turn off the screen to save power.

Turn On Screen

When the screen is off, please short press **[Power]** to wake up the screen.

Lock and Unlock

Lock

Please press **[Power]** to lock this screen to prevent some unexpected operations.

Unlock

After the screen is off, please press **[Power]** to wake up the screen, and then drag the slider upwards to the green ball to unlock the screen.

Switch desktops

In the idle mode, you can slide on the screen to switch between the 1st~5th screens.

Hot Icons

On the shortcut bar, touch  icon enters Dialer interface; touch  icon enters Contacts interface; touch  icon enters Messages interface; touch  icon enters Main Menu. touch  icon enters opera browser.

SIM Card Info.

You can view the operator information of SIM 1 and SIM 2 on Notification bar.

USB Status

You can view USB connection state.

Add to Home Screen

On the desktop, long press the blank area, you can display “Choose Wallpaper from”, and then operate the following: Gallery, Live Wallpapers, Wallpapers.

Bluetooth Connection

This device supports Bluetooth 4.0, you can listen to music with Bluetooth earphone. About Bluetooth settings and operations, please refer to the section of Bluetooth in System Settings.

Prompt: *Bluetooth function and operations are based on the real product.*

WLAN Connection

You can access to the local network through WiFi. About WiFi settings and operations, please refer to the WiFi section in System Settings.

Input Methods

This mobile phone is embedded one input method“ Android Keyboard”.Long press any input field to display the pop-up box of “Edit Text”, then touch “Input Method” to display the pop-up box of “Select Input Method”. In system settings, you can set Input languages, it supports English (United States) language in put and other kinds of languages’ input in settings

NOTE

Please keep your finger dry and clean when pressing the fingerprint identification sensor.



ILIKE F PRO

Rövid kezelési útmutató

Használati útmutató: <http://winmax.hu/>

Köszönjük, hogy **ILIKE** terméket vásárolt.

Az útmutató segít abban, hogy megismerje telefonja első üzembe helyezésének lépéseit és fontosabb funkcióit.

-Az útmutatóban leírtak eltérhetnek a terméktől és előzetes értesítés nélkül megváltozhatnak.

-A készülékek tartozékai régióként eltérőek lehetnek.

-A legjobb teljesítmény elérése érdekében használjon eredeti AKAI tartozékokat.

-A külön beszerezett tartozékok nem biztos, hogy kompatibilisek a készülékkel.

-A készülék az összes európai országban használható.

A Wi-Fi beltérben korlátozások nélkül használható, de Franciaországban kültéren tilos a használata.

A SIM kártya és az akkumulátor behelyezése

1. Vegye le a hátsó fedelet.

2.Helyezze be a SIM kártyát/kártyákat a megfelelő foglalatba az aranyszínű érintkezővel lefelé fordítva.

3.Helyezze be az akkumulátort.

4.Tegye vissza a hátsó fedelet.

Az akkumulátor feltöltése

A készülék használatbavétele előtt az akkumulátort teljesen fel kell tölteni.

Töltési lehetőségek:

1.hálózati adapterrel,USB kábel segítségével

2.PC-n keresztül, USB kábel segítségével.

Használatbavétel

A készüléket a bekapcsoló gomb hosszas megnyomásával kapcsolhatja be.

A kikapcsolást is ezzel a gombbal végezheti el.

További lehetőségek:

-Menü gomb: Nyomja meg a gombot, hogy megnyissa a menülistát. A menülistán belül tud további funkciókat, alkalmazásokat használni

-Kezdőlap gomb: Nyomja meg a gombot, hogy visszatérjen a készenléti képernyőre.

-Vissza gomb: Nyomja meg a gombot, hogy visszatérjen az előző képernyőre.

-Hangerő szabályzó gomb: A készülék hangerejének szabályozása.

A kijelző funkcióinak rövid ismertetése

Érintőképernyő: Az érintőképernyő, érintéssel és tartással valamint húzással vezérelhető.

Készenléti képernyő: A készenléti képernyőn ikonok, widgetek, alkalmazások gyorsgombjai találhatóak. Több panelből áll, balra vagy jobbra mozgatva válthat a panelok között.

Állapotjelző ikonok: A kijelző felső részén lévő ikonok jelzik az időt, a térerőt és más információkat.

Widgetek: Kényelmi funkciók és információk érhetőek el a widgetek által.

Értesítési panel: A képernyő felső részét megérintve és lehúzva jelenik meg. Számos információt tartalmaz.

A készülék feloldása

Ha készenléti állapotban van, akkor nyomja meg a bekapcsoló gombot, majd a megjelenő képernyőn húzza el a lakatot húzza el a megfelelő irányban. A kijelző feloldásához más lehetőségeket is meg lehet adni a Beállítások menüben.

Hívás kezdeményezése vagy fogadása

Hívás a telefonszám megadásával vagy a Névjegyből történő kiválasztással indítható. A korábbi hívások a hívásnaplóban érhetőek el. A hívások díjaiért keresse fel szolgáltatóját.

Üzenetek küldése/fogadása

Szöveges és multimédiás üzenetet valamint e-maileket küldhet a telefonnal. Az e-mailek küldése és fogadása előtt a telefonhoz kell adni egy e-mail fiókot. Az üzenetek küldése költséggel járhat, a díjakért érdeklődjön szolgáltatójánál.

Internet

A telefonnal csatlakozhat a világhálóra Wi-Fi vagy mobil adathálózat segítségével. A mobil adatforgalom költségekkel jár, a letölthető médiatartalmakért is kérhetnek külön díjat. A díjakról érdeklődjön szolgáltatójánál.

Alkalmazások megnyitása

Készenléti állapotban nyomja meg a Menü gombot. Jobbra vagy balra görgetve kiválaszthatja a kívánt alkalmazást a képernyőről. A Kezdőlap gomb hosszan tartó megnyomásával megnyithatja a legutóbb használt alkalmazások listáját.

FIGYELEM!

Ne használjon sérült kábelt vagy kilazult csatlakozókat.

Nedves kézzel ne érjen az USB kábelhez töltés közben.

Ne használja a készüléket töltés közben.

Vihar közben használat esetén megnő a villámcsapás veszélye.

Sérült vagy szivárgó akkumulátor esetén azonnal forduljon a márkaszervizhez.

Megjegyzés

Kérjük tartsa az ujját szárazon és tisztán, mikor használja az ujjlenyomat-azonosító szenzort.