


User Manual

LG-GB70S UVer:V1.4



Boxing list

1>Player to car: connection method



Special Note: Do not use your car ISOconnector to plug directly into the Player, otherwise it will burn out.

The player must be properly connected to the car in the way shown on the left, otherwise the player will not work properly

2>Camera: connection method



①




②



③

Link to the car R gear light on 2PIN, Note that you can not link the brake light power.



④

3>Player Testing(Check the wiring again)

- ➔ ① Player to Start up-right
- ➔ ② Touch Pad Sliding-right
- ➔ ③ FM Scan-right
- ➔ ④ FM Sound-right
- ➔ ⑤ R gear Camera Picture-right
- ➔ ⑥ Set date and Time with Time Memory-right




4>Test pass, press into the installation position



5>Mobile Phone interconnection use

IOS Phone Connect

Connect your IOS phone to the MP5 Device by the original USB Cable, then select "Trust" in the pop-up window of your IOS phone, enter the Phone password to trust the device, the image of your phone will auto display on the screen of MP5 Device.




Note: You can not click the MP5 screen to operate your IOS phone, this function only project the image of your phone's screen to Device Screen and sound of phone transmit to car speaker.

Note: If the device can not connect to the phone, please reboot the device and your phone both and try connect again.

Android Phone Connect


1. Connect your Android phone to the MP5 Device by the original USB Cable, then the link window will pop up on your phone, download and install the "Hi-Link" application. Open the "Hi-Link" application, authorize the application permissions, the image of your phone will display on the screen of MP5 Device.



2. Open the Bluetooth of your phone, search the Bluetooth name "CAR-KIT" of the device, paired and connected, if it want a pin code, please input "0000", after connect successful, the voice of your phone will transmit to the car speaker.



6.The beauty to be discovered by you



- ① Click this key shortly for power On. After power on, click this key shortly for MODE sele FM-USB AUDIO-TF AUDIO-AUX.
- ② Revolve the knob clockwise or anticlockwise to adjust the volume at will by your requirement.
- ③ T-Card play
- ④ AUX input audio
- ⑤ Reset key - Restore factory settings
- ⑥ U Disc and Mobile Phone Charging

7.Troubleshoot

Failure	Solution
No response to power on	Please press and hold the 1 button or check if the wiring is correct
No sound	Check wiring diagram,make sure the connection is righ
The button doesn't work	Check whether the keys have stuck
The radio doesn't work	Check whenether the connection of radil antenna is right
Search station automatically and couldn't stop	The local radio signal may be too weak,try to search the station hardly
No touch or Black screen after power on or the player does not work for a long time	Press key #5 - RST: Restore factory settings
Mobile Connect cannot connect to the car	Check the successful installation of the software; delete the mobile app process and connect again
The reversing camera often displays a blue screen or shows the reversing screen when braking	Check the reverse camera power wiring brake light, to connect the power of the R gear small light
The player won't start	Please check that the +- power supply is connected correctly? Check that the fuse is intact (replace)? Send a photo or video of the problem to your salesperson so we can fix it.
Nomemoryfunction,can'tsaveradiochannelanddate/time or Theplayerisalwayson	B+ and ACC are connected wrong, please check
Bluetoothdoesnotconnecttothephone	Please clear your phone's Bluetooth registration and reconnect to match