

Safety Instructions – Charcoal Grill

Only use the grill outdoors in a well-ventilated area. Never use indoors or in enclosed spaces.

Keep children and pets at a safe distance from the grill at all times.

Only use charcoal and firelighters that are suitable for grilling. Never use gasoline, alcohol, or other highly flammable liquids.

Do not add charcoal or firelighters once the grill is lit.


Allow the charcoal to burn out and the grill to cool completely before cleaning or storing.

Do not touch metal parts while the grill is hot – use heat-resistant gloves if necessary.

Place the grill on a stable, fireproof surface away from flammable materials (wood, fabric, dry grass, etc.).



Never leave the grill unattended during use.

Ensure proper disposal of ashes only after they are completely cold.




1					
2 Ax2		Bx2	Cx2	Dx4	Ex2
Fx1		Gx2	Hx1	Ix1	Jx1
Kx1		Lx1	Mx1	Nx2	Ox3
Px1		Qx1	Rx2	Tx1	Ux2
Vx1		Wx2	Xx14	Yx27	Zx41
		M4x $\frac{15}{0.6}$	M5x $\frac{15}{0.6}$	M5x $\frac{12}{0.5}$	$\frac{\Phi 5.4}{\Phi 0.2}$


Z1x2  $\frac{\Phi 8.2}{\Phi 0.3}$	Z2x41  M5	Z3x2  M8  mm inch x2	   M5 M8 €\$£ 
--	--	---	---




4



5



6



7

