

Safety Instructions – Charcoal Grill

Only use the grill outdoors in a well-ventilated area. Never use indoors or in enclosed spaces.

Keep children and pets at a safe distance from the grill at all times.

Only use charcoal and firelighters that are suitable for grilling. Never use gasoline, alcohol, or other highly flammable liquids.

Do not add charcoal or firelighters once the grill is lit.


Allow the charcoal to burn out and the grill to cool completely before cleaning or storing.

Do not touch metal parts while the grill is hot – use heat-resistant gloves if necessary.


















Place the grill on a stable, fireproof surface away from flammable materials (wood, fabric, dry grass, etc.).



Never leave the grill unattended during use.

Ensure proper disposal of ashes only after they are completely cold.




Parts


A  1pc	B  1pc	C  1pc	D  1pc
E  1pc	F  2pcs	G  2pcs	H  2pcs
I  2pcs	J  2pcs	K1  2pcs	K2  3pcs
K3  1pc	L  3pcs	M  3pcs	N  1pc
O1  1pc	O2  1pc	P1  1pc	P2  1pc
Q1  1pc	Q2  1pc	R  1pc	S  2pcs
T1  M6-50 6pcs	T2  M6-40 12pcs	T3  M5-25 6pcs	T4  M6-12 15pcs

T5  M4-10 16pcs	U  10*30 6pcs	V1  M8 2pcs	V2  M6 35 pcs			
V3  M5 6pcs	V4  M4 16pcs	W  4pcs	X1  M6 35PCS	X2  M5 6PCS	X3  M4 16PCS	X4  M8 2PCS


1




2





3





4





5




6





7





8





9





10





11



12



13



14

