





Warning



1. Please do not exceed the maximum load. Overweight may cause damage or drop of equipment.
2. Fits wooden wall, brick wall or concrete wall. Do not mount on drywall.
3. Walls must be able to carry 5 times the weight (total weight of the TV plus wall mount).
4. Please read the installation instructions carefully, we are not responsible for any damage or injury caused by improper, assembly or use! Any question, please contact our customer service.

Parts



Screw Package





Step 1 : Attach to the solid concrete wall


Draw point and punch.



Mount bolts.



Step 2 : Attach TV



Step 3 : Angle adjustment

