TAB 10

QUICK START GUIDE

Internet Tablet



Home
Menu
Back
Search
Volume Up
Volume Down
Power
Camera
Mic
Micro USB Port
Micro SD Slot
Headset Jack
Speaker
Camera
Mic
Micro USB Port
Micro SD Slot
Headset Jack
Power
Volume Up
Volume Down
Camera
Mic
Micro USB Port
Micro SD Slot
Headset Jack
Speaker
Camera
Mic
Micro USB Port
Micro SD Slot
Headset Jack
Power
Volume Up
Volume Down